

## Note before push the “ON” button

### Download Software instruction:

Download the software at <http://www.apresys.com/downloads/> , file name USB Temperature Data Logger Software.202 , and install the free software on PC

### Time Calibration Instruction:

Connect USB data logger with PC to calibrate local time before use

### Time Calibration Step:

- 1, Download software and install it on PC
- 2, Connect USB data logger with computer to calibrate local time before use
- 3, Click “Calibration Time” button on software main menu, Start time will be same as computer time, “Time Calibration has been completed” will appear at left bottom corner

Apresys TempTrak

Apresys®  
TempTrak

Download Save Open Print Calibration Time Start Setting Exit

Serial Number: D2510021371

Start Time: 2012-5-30 14:40

Stop Time: 2012-5-23 10:50

Sampling Interval: 00:05:00

Quantity of Data: 289

Description: Temp Record

Temp Max.: 80.04°F Temp Upper Limit: 32.00°F

Temp Min.: -22.11°F Temp Lower Limit: 32.00°F

Temp Avg.: -11.20°F

Summary Data

Time calibration has been completed

For other questions, email to [apresys009@hotmail.com](mailto:apresys009@hotmail.com)